CY7C1069AV33



2M x 8 Static RAM

Features

- High speed
 - t_{AA} = 10, 12 ns
- Low active power
- 990 mW (max.)
- Operating voltages of 3.3 ± 0.3V
- 2.0V data retention
- Automatic power-down when deselected
- TTL-compatible inputs and outputs
- Easy memory expansion with CE₁ and CE₂ features
- Available in Pb-free and non Pb-free 54-pin TSOP II, non Pb-free 60-ball fine-pitch ball grid array (FBGA) package

Functional Description

The CY7C1069AV33 is a high-performance CMOS Static RAM organized as 2,097,152 words by 8 bits. Writing to the device is accomplished by enabling the <u>chip</u> (by taking \overline{CE}_1 LOW and \overline{CE}_2 HIGH) and Write Enable (WE) inputs LOW.

<u>Rea</u>ding from the device is accomplished by enabling the chip $(\overline{CE}_1 \ LOW \ and \ CE_2 \ HIGH)$ as well as forcing the Output Enable (\overline{OE}) LOW while forcing the Write Enable (\overline{WE}) HIGH. See the truth table at the back of this data sheet for a complete description of Read and Write modes.

The input/output pins (I/O₀ through I/O₇) are placed in a high-impedance state when the device is deselected (\overline{CE}_1 HIGH or CE_2 LOW), the outputs are disabled (\overline{OE} HIGH), or during a Write operation (\overline{CE}_1 LOW, \overline{CE}_2 HIGH, and WE LOW).

The CY7C1069AV33 is available in a 54-pin TSOP II package with center power and ground (revolutionary) pinout, and a 60-ball fine-pitch ball grid array (FBGA) package.

Logic Block Diagram



Pin Configurations^[1, 2]

		OP II View	_
			N SC 05 CC4 N SC
V _{SS} ⊑ NC⊑	26 27	29 28	□V _{CC} □NC

198 Champion Court •



Selection Guide

	–10	-12	Unit
Maximum Access Time	10	12	ns
Maximum Operating Current	275	260	mA
Maximum CMOS Standby Current	50	50	mA

Pin Configurations^[1, 2](continued)



Notes:

NC pins are not connected on the die.
 DNU pins have to be left floating or tied to VSS to ensure proper application.



CY7C1069AV33

Maximum Ratings

(Above which the useful life may be impaired. For user guide lines, not tested.)	
Storage Temperature65°C to +150°C	
Ambient Temperature with Power Applied55°C to +125°C	
Supply Voltage on V _{CC} to Relative GND ^[3] –0.5V to +4.6V	,
DC Voltage Applied to Outputs in High-Z State $^{[3]}$ 0.5V to V_CC + 0.5V	,

DC Electrical Characteristics Over the Operating Range

Current into Outputs (LOW)...... 20 mA

Operating Range

Range	Ambient Temperature	v _{cc}
Commercial	0°C to +70°C	$3.3V\pm0.3V$
Industrial	–40°C to +85°C	

			_	10	–12		
Parameter	Description	Test Conditions	Min.	Max.	Min.	Max.	Unit
V _{OH}	Output HIGH Voltage	V _{CC} = Min., I _{OH} = -4.0 mA	2.4		2.4		V
V _{OL}	Output LOW Voltage	V _{CC} = Min., I _{OL} = 8.0 mA		0.4		0.4	V
V _{IH}	Input HIGH Voltage		2.0	$V_{CC} + 0.3$	2.0	V _{CC} + 0.3	V
V _{IL}	Input LOW Voltage ^[3]		-0.3	0.8	-0.3	0.8	V
I _{IX}	Input Leakage Current	$GND \leq V_I \leq V_{CC}$	-1	+1	-1	+1	μA
I _{OZ}	Output Leakage Current	$GND \leq V_{OUT} \leq V_{CC}$, Output Disabled	-1	+1	-1	+1	μA
I _{CC}		$V_{CC} = Max.,$ f = f _{MAX} = 1/t _{RC}		275		260	mA
I _{SB1}	Power-down Current	$\begin{array}{l} CE_2 \leq V_{IL}, \\ Max. V_{CC}, \overline{CE}_1 \geq V_{IH} \\ V_{IN} \geq V_{IH} \text{ or } V_{IN} \leq V_{IL}, f = f_{MAX} \end{array}$		70		70	mA
I _{SB2}	Power-down Current	$\begin{array}{l} \underline{CE}_2 \leq 0.3V, Max. V_{CC}, \\ \overline{CE}_1 \geq V_{CC} - 0.3V, \\ V_{\text{IN}} \geq V_{CC} - 0.3V, \\ \text{or} V_{\text{IN}} \leq 0.3V, \text{f} = 0 \end{array}$		50		50	mA

Capacitance^[4]

Parameter	Description	Test Conditions	TSOP II	FBGA	Unit
C _{IN}	Input Capacitance	$T_A = 25^{\circ}C, f = 1 \text{ MHz}, V_{CC} = 3.3 \text{V}$	6	8	pF
C _{OUT}	I/O Capacitance		8	10	pF

AC Test Loads and Waveforms^[5]



Notes:

- 3. V_{IL} (min.) = -2.0V for pulse durations of less than 20 ns.
 4. Tested initially and after any design or process changes that may affect these parameters.
 5. Valid SRAM operation does not occur until the power supplies have reached the minimum operating V_{DD} (3.0V). As soon as 1ms (T_{power}) after reaching the minimum operating V_{DD}, normal SRAM operation can begin including reduction in V_{DD} to the data retention (V_{CCDR}, 2.0V) voltage.



AC Switching Characteristics Over the Operating Range ^[7]

		_	10	-	12	
Parameter	Description	Min.	Max.	Min.	Max.	Unit
Read Cycle	·	•	•	•		
t _{power}	V _{CC} (typical) to the First Access ^[8]	1		1		ms
t _{RC}	Read Cycle Time	10		12		ns
t _{AA}	Address to Data Valid		10		12	ns
t _{OHA}	Data Hold from Address Change	3		3		ns
t _{ACE}	CE ₁ LOW/CE ₂ HIGH to Data Valid		10		12	ns
t _{DOE}	OE LOW to Data Valid		5		6	ns
t _{LZOE}	OE LOW to Low-Z ^[9]	1		1		ns
t _{HZOE}	OE HIGH to High-Z ^[9]		5		6	ns
t _{LZCE}	CE ₁ LOW/CE ₂ HIGH to Low-Z ^[9]	3		3		ns
t _{HZCE}	CE ₁ HIGH/CE ₂ LOW to High-Z ^[9]		5		6	ns
t _{PU}	CE ₁ LOW/CE ₂ HIGH to Power-up ^[10]	0		0		ns
t _{PD}	CE ₁ HIGH/CE ₂ LOW to Power-down ^[10]		10		12	ns
Write Cycle ^[10, 11]	·	•	•	•		
t _{WC}	Write Cycle Time	10		12		ns
t _{SCE}	CE ₁ LOW/CE ₂ HIGH to Write End	7		8		ns
t _{AW}	Address Set-up to Write End	7		8		ns
t _{HA}	Address Hold from Write End	0		0		ns
t _{SA}	Address Set-up to Write Start	0		0		ns
t _{PWE}	WE Pulse Width	7		8		ns
t _{SD}	Data Set-up to Write End	5.5	1	6		ns
t _{HD}	Data Hold from Write End	0		0		ns
t _{LZWE}	WE HIGH to Low-Z ^[9]	3		3		ns
t _{HZWE}	WE LOW to High-Z ^[9]		5		6	ns

Data Retention Waveform



Notes:

- Valid SRAM operation does not occur until the power supplies have reached the minimum operating V_{DD} (3.0V). As soon as 1ms (T_{power}) after reaching the minimum operating V_{DD}, normal SRAM operation can begin including reduction in V_{DD} to the data retention (V_{CCDR}, 2.0V) voltage.
 Test conditions assume signal transition time of 3 ns or less, timing reference levels of 1.5V, input pulse levels of 0 to 3.0V, and output loading of the specified l_{DL}/l_{OH} and transmission line loads. Test conditions for the Read cycle use output loading shown in part a) of the AC test loads, unless specified otherwise. 8. This part has a voltage regulator which steps down the voltage from 3V to 2V internally. t_{power} time has to be provided initially before a Read/Write operation is
- started.
- 9. t_{HZOE}, t_{HZSCE}, t_{HZWE} and t_{LZOE}, t_{LZCE}, and t_{LZWE} are specified with a load capacitance of 5 pF as in (b) of AC Test Loads. Transition is measured ±200 mV from steady-state voltage.
- 10. These parameters are guaranteed by design and are not tested.
 11. The internal Write time of the memory is defined by the overlap of CE₁ LOW/CE₂ HIGH, and WE LOW. CE₁ and WE must be LOW along with CE₂ HIGH to initiate a Write, and the transition of any of these signals can terminate the Write. The input data set-up and hold timing should be referenced to the leading edge of the signal that terminates the Write.
- 12. The minimum Write cycle time for Write Cycle No. 3 (WE controlled, OE LOW) is the sum of t_{HZWE} and t_{SD}.



CY7C1069AV33

Switching Waveforms

Read Cycle No. 1^[13, 14]



Read Cycle No. 2 (OE Controlled)^[14, 15]



Notes:

13. <u>Device</u> is continuously selected. $\overline{CE}_1 = V_{IL}$, $CE_2 = V_{IH}$. 14. WE is HIGH for Read cycle.

15. Address valid prior to or coincident with \overline{CE}_1 transition LOW and CE_2 transition HIGH.



Switching Waveforms (continued)

Write Cycle No. 1 ($\overline{\text{CE}}_1$ Controlled)^[16, 17, 18]



Write Cycle No. 2 ($\overline{\text{WE}}$ Controlled, $\overline{\text{OE}}$ LOW)^[16, 17, 18]



Truth Table

CE ₁	CE ₂	OE	WE	I/O ₀ -I/O ₇	Mode	Power
Н	Х	Х	Х	High-Z	Power-down	Standby (I _{SB})
Х	L	Х	Х	High-Z	Power-down	Standby (I _{SB})
L	н	L	Н	Data Out	Read All Bits	Active (I _{CC})
L	н	Х	L	Data In	Write All Bits	Active (I _{CC})
L	Н	Н	Н	High-Z	Selected, Outputs Disabled	Active (I _{CC})
				•		-

Notes:

16. Data I/O is high-impedance if $\overline{OE} = V_{IH}$. 17. If \overline{CE}_1 goes HIGH/CE₂ LOW simultaneously with \overline{WE} going HIGH, the output remains in a high–impedance state. 18. \overline{CE} above is defined as a combination of \overline{CE}_1 and CE_2 . It is active low.



Ordering Information

Speed (ns)	Ordering Code	Package Diagram	Package Type	Operating Range
10	CY7C1069AV33-10ZC	51-85160	54-pin TSOP II	Commercial
	CY7C1069AV33-10ZXC	1	54-pin TSOP II (Pb-free)	
	CY7C1069AV33-10BAC	51-85162	60-ball (8 mm x 20 mm x 1.2 mm) FBGA	
	CY7C1069AV33-10ZI	51-85160	54-pin TSOP II	Industrial
	CY7C1069AV33-10ZXI	1	54-pin TSOP II (Pb-free)	
	CY7C1069AV33-10BAI	51-85162	60-ball (8 mm x 20 mm x 1.2 mm) FBGA	
12	CY7C1069AV33-12ZC	51-85160	54-pin TSOP II	Commercial
	CY7C1069AV33-12ZXC	1	54-pin TSOP II (Pb-free)	
	CY7C1069AV33-12BAC	51-85162	60-ball (8 mm x 20 mm x 1.2 mm) FBGA	
	CY7C1069AV33-12ZI	51-85160	54-pin TSOP II	Industrial
	CY7C1069AV33-12ZXI	1	54-pin TSOP II (Pb-free)	
	CY7C1069AV33-12BAI	51-85162	60-ball (8 mm x 20 mm x 1.2 mm) FBGA	

Package Diagrams



54-pin TSOP II (51-85160)



Package Diagrams (continued)



60-ball FBGA (8 mm x 20 mm x 1.2 mm) (51-85162)

All product and company names mentioned in this document may be the trademarks of their respective holders

© Cypress Semiconductor Corporation, 2006. The information contained herein is subject to change without notice. Cypress Semiconductor Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in a Cypress product. Nor does it convey or imply any license under patent or other rights. Cypress products are not warranted nor intended to be used for medical, life support, life saving, critical control or safety applications, unless pursuant to an express written agreement with Cypress. Furthermore, Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress products in life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.



Document History Page

	Document Title: CY7C1069AV33 2M x 8 Static RAM Document Number: 38-05255							
REV.	ECN NO.	Issue Date	Orig. of Change	Description of Change				
**	113724	03/27/02	NSL	New Data Sheet				
*A	117060	07/31/02	DFP	Removed 15-ns bin				
*В	117990	08/30/02	DFP	Added 8-ns bin Changing I_{CC} for 8, 10, 12 bins t_{power} changed from 1 µs to 1 ms Load Cap Comment changed (for Tx line load) t_{SD} changed to 5.5 ns for the 10-ns bin Changed some 8-ns bin #'s (t_{HZ} , t_{DOE} , t_{DBE}) Removed hz < Iz comments				
*C	120385	11/13/02	DFP	Final Data Sheet Added note 4 to "AC Test Loads and Waveforms" and note 7 to t _{pu} and t _{pd} Updated Input/Output Caps (for 48BGA only) to 8 pf/10 pf and for the 54-pin TSOP to 6/8 pf				
*D	124441	2/25/03	MEG	Changed ISB1 from 100 mA to 70 mA Shaded the 48fBGA product offering information				
*E	403984	See ECN	NXR	Changed the Logic Block Diagram On page # 1 Added notes under Pin Configuration Changed the Package diagram of 51-85162 from Rev *A to Rev *D Changed 48-Ball FBGA to 60-Ball FBGA in Pin Configuration Updated the Ordering Information				
*F	492137	See ECN	NXR	Removed 8 ns speed bin from product offering Changed the description of $I_{ X}$ from Input Load Current to Input Leakage Current in DC Electrical Characteristics table Updated the Ordering Information				