Red Laser Diode



Overview

DL-3147-021 is index guided 645 nm (Typ.) AlGaInP laser diode with low threshold current. The low threshold current is achieved by a strained multiple quantum well active layer. DL-3147-021 is suitable for laser pointer.

Features

- Short wavelength
- Low threshold current
- Low operating voltage
- Small package

: 645 nm (Typ.) : Ith = 30 mA (Typ.)

- : Vop = 2.3 V (Typ.)
- : 5.6 mm ø

Absolute Maximum Ratings at Tc=25°C

Parameter		Symbol	Ratings	Unit	
Light Output		Ро	5	mW	
Reverse Voltage	Laser PIN	VR	2 30	V	
Operating Temperature		Topr	-10 to +40	°C	
Storage Temperature		Tstg	-40 to +85	°C	

Electrical and Optical Characteristics at Tc=25°C

Para	meter	Symbol	Condition	Min.	Тур.	Max.	Unit
Threshol	d Current	Ith	CW	-	30	50	mA
Operatin	g Current	Iop	Po=5mW	-	45	60	mA
Operatin	g Voltage	Vop	Po=5mW	-	2.3	2.6	V
Lasing W	avelength	λ p	Po=5mW	-	645	660	nm
Beam *)	Perpendicular	$\theta \perp$	Po=5mW	25	30	40	deg.
Divergence	Parallel	heta //	Po=5mW	6	7.5	10	deg.
Off Axis	Perpendicular	$\Delta heta \perp$	-	-	-	±3	deg.
Angle	Parallel	$\Delta heta$ //	-	-	-	±3	deg.
Differentia	l Efficiency	dPo/dIop	-	0.2	0.4	0.8	mW/mA
Monitoring C	Output Current	Im	Po=5mW	0.15	0.4	0.75	mA
Astigr	natism	As	Po=5mW	-	8	-	μm

*) Full angle at half maximum note : The above product specifications are subject to change without notice.

SANYO Electric Co., Ltd. Semiconductor Bussiness Headquarters TOKYO OFFICE Tokyo Bldg., 1-10, 1 Chome, Ueno, Taito-ku, TOKYO, 110-8534 JAPAN

Package Dimensions



Electrical Connection



Characteristics



Output power vs. Forward current





Monitor current vs. Output power



Beam divergence



Output power vs. Lasing wavelength









- 1. No products described or contained herein are intended for use in surgical implants, life-support systems, aerospace equipment, nuclear power control systems, vehicles, disaster / crime-prevention equipment or the like, and the failure of which may directly or indirectly cause injury, death or property loss.
- 2. Anyone purchasing any products described or contained herein for an above-mentioned use shall:
 - 1) Accept full responsibility and indemnify and defend SANYO ELECTRIC CO.,LTD., it's affiliates, subsidiaries and distributors or any of their officers and employees, jointly and severally, against any and all claims and litigation and all damages, costs and expenses associated with such use.
 - Not impose any responsibility for any fault or negligence which may be cited in any such claim or litigation on SANYO ELECTRIC CO., LTD., it's affiliates, subsidiaries and distributors or any of their officers and employees jointly or severally.
- 3. Information (including circuit diagrams and circuit parameters) disclosed herein is for example only; it is not guaranteed for mass production, SANYO believes the information disclosed herein is accurate and reliable, but no guarantees are made or implied regarding it's use or any infringements of intellectual property rights or other rights of third parties.

Precautionary instructions in handling gallium arsenic products

Special precautions must be taken in handling this product because it contains, gallium arsenic, which is designated as a toxic substance by law. Be sure to adhere strictly to all applicable laws and regulations enacted for this substance, particularly when it comes to disposal.

Manufactured by ; Tottori SANYO Electric Co., Ltd. Electronics Device Bussiness Headquaters LED Division 5-318, Tachikawa-cho, Tottori City, 680-8634 Japan TEL: +81-857-21-2137 FAX: +81-857-21-2161